


404HV-CN (B88)



**404HV-CN****404HV-CN (B88)**

#	PART #	DESCRIPTION	QTY	Note
1	53230AG	404 COVER 1.5" INLET, 1.5" VENT, 1.5" DISCHARGE	1	
2	5360000	404/405 QUICK TREE FLOAT ROD	1	
3	K001153	404 TANK	1	
4	8156000	TRUSS HD, 1/4-20X3/4 18-8 SCREW	14	
5	8157000	TRUSS HD 1/4-20 X 1 18-8 SCREW	1	
6	40500A0	TOE NIPPLE PVC SCH 80 7.125 IN	1	
7	5045000	FLOAT SUPPORT CLAMP 10-24	1	
9	404HV-CNP	REPLACEMENT 404HV-CN PUMP ONLY	1	
10	532400B	ACCESS COVER	1	[1]
11	K001151	ACCESS COVER KIT, INCLUDES HARDWARE	1	
12	53250J0	FLOAT SWITCH ASSEMBLY, 10 FT. , 230 VOLT	1	
13	K001152	COVER KIT, INCLUDES ACCESS COVER AND HARDWARE	1	
14	K001187	TANK, COVER, ACCESS COVER, HARDWARE	1	

**PART NOTES:**

[1] - Part requires factory authorized service. Contact Liberty Pumps at 1-800-543-2550