


404L

# 404L (B37)



404L (B37)

404L (B37).pdf

PAGE

**404L****404L (B37)**

#	PART #	DESCRIPTION	QTY	Note
1	53230CG	404L COVER 2" INLET 2" VENT 2" DISCHARGE	1	
2	5360000	404/405 QUICK TREE FLOAT ROD	1	
3	K001153	404 TANK	1	
4	8156000	TRUSS HD, 1/4-20X3/4 18-8 SCREW	14	
5	8157000	TRUSS HD 1/4-20 X 1 18-8 SCREW	1	
6	40500A0	TOE NIPPLE PVC SCH 80 7.125 IN	1	
7	5045000	FLOAT SUPPORT CLAMP 10-24	1	
10	532400B	ACCESS COVER	1	[1]
11	K001151	ACCESS COVER KIT, INCLUDES HARDWARE	1	
12	K001155	SWITCH TREE KIT	1	
13	K001167	COVER KIT, INCLUDES ACCESS COVER AND HARDWARE	1	
14	K001188	TANK, COVER, ACCESS COVER AND HARDWARE	1	
15	4029BA0	PUMP AND DISCHARGE PIPE	1	[2]

**PART NOTES:**

- [1] - Part requires factory authorized service. Contact Liberty Pumps at 1-800-543-2550  
[2] - [click herefor 4029BA0 replacement parts](#)